

Guide to the Remote Controller function:

General RC commands

P+/P- and Arrow buttons – navigate through pages, groups and channels.

??, Wheel, Up/Down – load channel list in Play mode.

INFO, INFOx2 – show programme information.

Number Keys – direct channel selection. “0” – previous channel in Play mode.

BACK – hide channel list and info; go back to primary list.

RATIO, Q.MENU – picture ratio.

PLAY – reload window; STOP – relaunch stream.

PAUSE – show stream link.

RED – switch to DVB input and back.

GREEN – EPG (Electronic Programme Guide) + Archive (if supported).

YELLOW – All channels, show digital clock in Play mode.

BLUE – Groups, Constant Infobar.